


# BODY PANELS XJ S1/2/3 MODELS



BONNET ASSEMBLY <span style="float: right;">Item 1</span>		
MODEL	PART No	QTY PER VEHICLE
S1	11697	1
S2/S3	AKP464	1

FRONT CROSSMEMBER <span style="float: right;">Item 2</span>		
MODEL	PART No	QTY PER VEHICLE
ALL MODELS	12101	1

FRONT LOWER VALANCE <span style="float: right;">Item 3</span>		
MODEL	PART No	QTY PER VEHICLE
S1	11702	1
S2	JS675	1
S3	JS683	1

BONNET HINGES <span style="float: right;">Item 4</span>		
MODEL	PART No	QTY PER VEHICLE
S1	12060 RH 12061 LH	1 1
S2	JS678 RH JS679 LH	1 1
S3	AKP746 RH AKP747 LH	1 1

FRONT WINGS <span style="float: right;">Item 5</span>		
MODEL	PART No	QTY PER VEHICLE
S1	JS388 RH JS389 LH	1 1
S2	JS676 RH JS677 LH	1 1
S3	AKP374 RH AKP375 LH	1 1

FRONT WING NOSE SECTIONS <span style="float: right;">Item 5A</span>		
MODEL	PART No	QTY PER VEHICLE
S2	JS676RP RH JS677RP LH	1 1
S3	AKP374RP RH AKP375RP LH	1 1

FRONT WING STONEGUARDS <span style="float: right;">Item 6</span>		
MODEL	PART No	QTY PER VEHICLE
ALL MODELS	AKP740 RH (Upper) AKP741 LH (Upper)	1 1

FRONT WING STONEGUARDS <span style="float: right;">Item 7</span>		
MODEL	PART No	QTY PER VEHICLE
ALL MODELS	BD38380 RH (Lower) BD38381 LH (Lower)	1 1

FRONT DOORS <span style="float: right;">Item 8</span>		
MODEL	PART No	QTY PER VEHICLE
S1	JS413 RH JS414 LH	1 1
S2 4 DOOR (Manual Windows)	RTC651 RH RTC652 LH	1 1
S2 4 DOOR (Electric Windows)	RTC655 RH RTC656 LH	1 1
S2 COUPE (2 Door)	JS671 RH JS672 LH	1 1
S3	AKP470 RH AKP471 LH	1 1

FRONT DOOR SKINS <span style="float: right;">Item 9</span>		
MODEL	PART No	QTY PER VEHICLE
S1 & S2 (4 Door)	JS458 RH JS459 LH	1 1
S2 Coupe (2 Door)	JS668 RH JS670 LH	1 1
S3	AKP2 RH AKP3 LH	1 1

FRONT DOOR HINGES <span style="float: right;">Item 10</span>		
MODEL	PART No	QTY PER VEHICLE
ALL MODELS	AKP250 RH Upper AKP251 LH Upper AKP252 RH Lower AKP253 LH Lower	1 1 1 1

REAR DOORS <span style="float: right;">Item 11</span>		
MODEL	PART No	QTY PER VEHICLE
S1 SHORT WHEEL BASE	JS415 RH JS416 LH	1 1
S1 LONG WHEEL BASE	JS609 RH JS610 LH	1 1
S2 SHORT WHEEL BASE	RTC653 RH RTC654 LH	1 1
S2 LONG WHEEL BASE	RTC531 RH RTC532 LH	1 1
S3	AKP474 RH AKP475 LH	1 1

REAR DOOR SKINS <span style="float: right;">Item 12</span>		
MODEL	PART No	QTY PER VEHICLE
S1 & S2 SHORT WHEEL BASE	JS460 RH JS461 LH	1 1
S1 & S2 LONG WHEEL BASE	JS607 RH JS608 LH	1 1
S3	AKP4 RH AKP5 LH	1 1

REAR DOOR HINGES <span style="float: right;">Item 13</span>		
MODEL	PART No	QTY PER VEHICLE
ALL MODELS	AKP1202 RH Upper AKP1203 LH Upper AKP1200 RH Lower AKP1201 LH Lower	1 1 1 1



TOE BOARDS			Item 14
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12096 RH 12097 LH	1 1	

FLOORS			Item 15
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS (Floors to be cut for SWB models)	JS604 RH JS605 LH	1 1	

INNER SILLS			Item 16
MODEL	PART No	QTY PER VEHICLE	
S1 & S2 (Sills to be cut for SWB models)	JS599 RH JS600 LH	1 1	
S3	AKP380 RH AKP381 LH	1 1	

OUTER SILLS			Item 17
MODEL	PART No	QTY PER VEHICLE	
S1 & S2 (Except Coupe) & S3 (Sill to be cut for SWB Models)	JS593 RH JS594 LH	1 1	
S2 Coupe (2 door)	JS701 RH JS710 LH	1 1	

SILL CLOSING PANELS (FRONT)			Item 18
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12198 RH 12220 LH	1 1	

SILL CLOSING PANELS (REAR)			Item 19
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12510 RH 12511 LH	1 1	

BOOT LID ASSEMBLY			Item 20
MODEL	PART No	QTY PER VEHICLE	
S1	11698	1	
S2	JS673	1	
S3	AKP373	1	

BOOT LID HINGES			Item 21
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12080 RH 12081 LH	1 1	

REAR WINGS			Item 22
MODEL	PART No	QTY PER VEHICLE	
S1 & S2 (Except Coupe)	JS469 RH JS470 LH	1 1	
S2 COUPE (2 Door)	JS702 RH JS711 LH	1 1	
S3	AKP346 RH AKP347 LH	1 1	

REAR WHEEL ARCH REPAIR			Item 22A
MODEL	PART No	QTY PER VEHICLE	
S1 & S2 (Except Coupe) & S3	JS469RP RH JS470RP LH	1 1	
S2 COUPE (2 Door)	JS702RP RH JS711RP LH	1 1	

REAR WING REPAIR			Item 22B
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	AKP346RP RH AKP347RP LH	1 1	

REAR WING VALANCES			Item 23
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	RTC647 RH RTC648 LH	1 1	

REAR CENTRE VALANCE			Item 24
MODEL	PART No	QTY PER VEHICLE	
S1	11703	1	
S2 & S3	RTC1214	1	

REAR WHEEL ARCH PANEL (FRONT)			Item 25
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12147 RH 12148 LH	1 1	

REAR WHEEL ARCH PANEL (REAR)			Item 26
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12149 RH 12150 LH	1 1	

REAR WHEEL ARCH PANEL (INNER)			Item 27
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12151 RH 12152 LH	1 1	

REAR QTR VALANCES			Item 28
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	11870 RH 11871 LH	1 1	

BOOT FLOOR ASSEMBLY			Item 29
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12128	1	

BOOT FLOOR			Item 30
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	RTC539	1	

BOOT SIDE PANELS			Item 31
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12130 RH 12131 LH	1 1	

REAR BOOT CROSS MEMBER			Item 32
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	RTC1185	1	

CROSS MEMBER MNTG. PANEL			Item 33
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	RTC646	1	

VALANCE EXTENSIONS			Item 34
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12137 RH 12138 LH	1 1	

REAR SIDE MEMBERS			Item 35
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12135 RH 12136 LH	1 1	

REAR SIDE MEMBER REPAIRS			Item 35A
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	12135RP RH 12136RP LH	1 1	

RADIUS ARM MOUNTING			Item 36
MODEL	PART No	QTY PER VEHICLE	
ALL MODELS	JS254	2	